


Frequency Response


Dakota Audio

FA-501 & FA-602


EQ SWITCH- MUSIC



EQ SWITCH- VOICE W/MUSIC



EQ SWITCH- VOICE



A three position switch on the control panel adjusts the frequency response for the program material.

“MUSIC”: provides full range sound.

“VOICE W/MUSIC”: position has a slight rise in the high frequency response to enhance voice intelligibility while maintaining good music reproduction.

“VOICE”: position reduces low frequencies for maximum voice intelligibility.